

# Security Control Systems, Inc.

## DMP XR200 Fire Alarm Keypad

Your Alarm System uses an English display keypad that is menu driven. Throughout its operation it will prompt you by asking you a series of questions. To answer the questions simply push the white button that is directly under the answer you wish to choose.

For example: If the keypad reads "Bypass No Yes" and you want to bypass, then push the white button that is directly under the word "Yes".

If you have questions concerning the operation of your system, please call: 952.736.9349. If you wish to cancel and alarm or test your system, please call: 952.854.8270 or 800.432.9250.

**To Silence Horn/Strobes:** Push command button until keypad reads "Menu". Select "Yes" + 4 digit code. The keypad will read "Sensor Reset". Press the "command" button and the keypad will read "

**To Reset Fire Sensors and Clear 24 Hour Zones from Alarm Memory:** Push Command Button until keypad reads "Menu". Select "Yes" + 4 digit code. The keypad will read "Sensor Reset". Push any white button.

**To Silence Keypad Trouble Buzzer:** Push any white button. (Some types of troubles may also require you to enter your 4 digit code).